



















P4

• Negative loads are tension load.

P3



KB-M36R Placing Boom System Technical data (Anchor type & Floor Type)

For the safety of equipment, our company limits wind speed when In operation (I/S) or out of operation (O/S), and measures for each wind speed are as follows.

1. Anchor Type

- 1) When the wind speed is more than 20m/s but less than 33m/s.
 - Work must be stopped and the boom must be stored perpendicular to the gound.



- 2) When the wind speed is more than 33m/s but less than 47m/s.
 - As shown in [Figure 1] below, Please disassemble entire booms exclude the 1st-1 boom. And store them in a stable place.





- 3) When the wind speed is more than 47m/s but less than 60m/s.
 - As shown in [Figure 2] below, Please disassemble entire boom excluding the mast. And store them in a stable place.



[Figure 2]

4) If wind speed is over 60m/s, disassemble entire Boom and mast. And store them in a stable place.

2. Floor Type (Climbing Type)

- 1) When the wind speed is more than 20m/s but less than 42m/s.
 - Work must be stopped and the boom must be stored perpendicular to the gound.





- 2) When the wind speed is more than 42m/s but less than 47m/s.
 - As shown in [Figure 1] below, Please disassemble entire booms exclude the 1st-1 boom. And store them in a stable place.



[Figure 1]

3) When the wind speed is more than 47m/s but less than 60m/s.

- As shown in [Figure 2] below, Please disassemble entire boom excluding the mast. And store them in a stable place.



[Figure 2]

4) If wind speed is over 60m/s, disassemble entire Boom and mast. And store them in a stable place.



PLACING BOOM SYSTEM ----- [BOOM ASS'Y & UPPER PARTS]





PLACING BOOM SYSTEM ----- [MAST]





PLACING BOOM SYSTEM ----- [FRAME _ CLIMBING, CLIMBING_CYLINDER]



TOTAL : 160 kg

0



1000















KB-M36R TYPE

